

TTSD/HD

Item	Qty	Description
A	2	M16 x 60 Bolts & Nyloc Nuts
B	2	M8 x 30 Bolts & Nyloc Nuts
C	4	8 x 25 Flat Washers
D	1	Heavy Duty Double Step
E	1	Socket Plate 2

1. Using Item **A** fit Item **D** and your desired ball bracket (Not supplied in this kit) to the Towbar face plate.
2. Using Item **B** with Item **C** fit Item **E** to the mounting holes found in the tread pattern.
3. Fully tighten all fixings ensuring the step is rigid, square and secure.

